

Quick Start Guide | Purple Adjustable Base



See Owner's Manual for complete operating instructions.

View set-up video here:



Part List

Before discarding the packing materials ensure all the parts are accounted for. Some parts may be attached to the base or inside boxes, please inspect carefully.

Wired Remote Control	Mattress Retainer Bar	Legs ②	Power Cord	Power Supply	Battery Backup Strap	Connecting Strap (TL/CKS only)

Miscellaneous Parts (not included): Sync Cord, Surge Protector, 9 Volt Alkaline Batteries ②

All electronics and components that need to be installed are located in boxes under the base or attached to the frame.

STEP 1

Remove the bed base from the box keeping the bottom of the base facing upwards.

Remove the binding straps and packing materials, making sure not to puncture the box with any sharp objects.

STEP 2

Legs are shipped fully assembled. Alternative heights in 3" increments can be achieved by removing leg segments.

To install the legs, thread the washer over the bolt of the leg with the recessed side facing the leg, and tighten by hand. **Do not over tighten.**



STEP 3

Uncoil the Head Motor Cord and plug it into the Power Supply.



STEP 4

Plug the wired remote control into the head motor splitter cable.

STEP 5

Carefully flip the base over on to its legs. Important: Two people are required to move the bed base. Do not drag across the floor. Do not rest frame on its side, excessive pressure may damage the legs.

STEP 6

Insert the Power Cord into the Power Supply.



STEP 7

Plug the Power Cord into a power outlet. **A surge protector is recommended.**

STEP 8

Place each end of the mattress retainer bar into the inserts at the foot of the base until the retainer bar is secured in place.



Setup is now complete! Quickly test remote functions to verify proper setup and return the base to a flat position before placing the mattress on top.